



YSC9730-1

ディスプレイスクリーン(片面用)
W:950 D:500 H:1400



YSC9730-2

ディスプレイスクリーン(片面用)
W:950 D:500 H:1970



YSC9730-4

棚
W:950 D:500 H:1400



YSC9730-6

生地掛
W:950 D:500 H:1400



YSC9730-10

傘置(折畳傘用・両面)
W:950 D:500 H:1400



YSC9730-11

靴置(両面用)
W:950 D:720 H:1400

【マテリアル】 木：化粧合板 スチール：白塗装・クロームメッキ

PANEL

YSC9730-12

生地掛
W:950 D:500 H:1970




YSC9730-15


バッグ掛(両面用)
W:950 D:500 H:1400

YSC9730のパーツアタッチメント


9730- a スクリーン用




9730- f ステージ(P板フラッシュ:ホワイト)




9730- q 傘立て




9730- t ショルダーバッグ掛




9730- l 靴置




9730- d1 ガラス棚




9730- u 傾斜ハンガー




9730- n 折り畳み傘立て




9730- h ニッチ用棚(P板フラッシュ:ホワイト)




9730- d2 棚(P板フラッシュ:ホワイト)




9730- v 帽子掛




9730- i ニッチ用ハンガーバー



9730- m 生地掛



9730- p 傘置



9730- S1 S2 ハンガーバー
φ22.2

